

**LOWEPRO RIDGE SERIES MATRIX 2006**



Ridge 10



Ridge 20



Ridge 30



Ridge 60

		Ridge 10	Ridge 20	Ridge 30	Ridge 60
<b>Argus</b>	DC-3200	•			
	DC-3520/3640	•			
<b>BenQ</b>	DC C35/40/50/51/60/62			•	
	DC C500	•			
	DC C530	•			
	DC C630	•			
	DC C800		•		
	DC E30/40/41/43/53	•			
	DC E520+	•			
	DC E600	•			
	DC S40			•	
	DC X600	•			
	DC-2410			•	
DC-3410		•			
<b>Canon</b>	Digital IXUS 430/500	•			
	Digital IXUS 55	•			
	Digital IXUS 750	•			
	Digital IXUS i/i5	•			
	Digital IXUS II/30/40	•			
	Digital IXUS Wireless	•			
	IXUS 30	•			
	IXUS 40	•			
	IXUS 50	•			
	IXUS 70	•			
	IXUS V	•			
	Optura 600				•
	PowerShot A300/A310	•			
	PowerShot A400		•		
	PowerShot A410			•	
	PowerShot A420		•		
	PowerShot A430		•		
	PowerShot A510/520			•	
	PowerShot A530			•	
	PowerShot A540			•	
	PowerShot A610				•
	PowerShot A620				•
	PowerShot A630				•
	PowerShot A640				•
	PowerShot A700			•	
	PowerShot A710 IS			•	
	PowerShot A80/A85			•	
	PowerShot A95		•		
	PowerShot G7				•
	PowerShot S10/S20		•		
	PowerShot S110	•			
	PowerShot S3 IS				•
	PowerShot S60			•	
	PowerShot S70			•	
	PowerShot S80		•		
	PowerShot SD 600/Digital IXUS 60	•			
	PowerShot SD 630/Digital IXUS 65	•			
	PowerShot SD10/SD20/IXY Digital	•			
	PowerShot SD30	•			
	PowerShot SD40/Ixus i7	•			
	PowerShot SD400	•			
	PowerShot SD430 Wireless	•			
PowerShot SD450	•				
PowerShot SD550	•				
PowerShot SD700 IS/Digital IXUS 800 IS	•				
PowerShot SD800 IS/Digital IXUS 850 IS	•				
PowerShot SD900 IS/Digital IXUS 900 Ti	•				

LOWEPRO RIDGE SERIES MATRIX X 2006



Ridge 10



Ridge 20








Ridge 30








Ridge 60

		Ridge 10	Ridge 20	Ridge 30	Ridge 60
<b>Casio</b>	EXILIM EX-M20U/S20U	•			
	EXILIM EX-S100	•			
	EXILIM EX-S500	•			
	Exilim EX-S600	•			
	Exilim EX-S600D	•			
	EXILIM EX-Z10	•			
	Exilim EX-Z1000	•			
	EXILIM EX-Z110	•			
	EXILIM EX-Z120	•			
	EXILIM EX-Z3/Z4/Z4U	•			
	EXILIM EX-Z30/Z40/Z40LE	•			
	Exilim EX-Z5	•			
	EXILIM EX-Z50/Z55	•			
	EXILIM EX-Z500	•			
	EXILIM EX-Z57/Z750	•			
	Exilim EX-Z60	•			
	Exilim EX-Z600	•			
	Exilim EX-Z7	•			
	Exilim EX-Z70	•			
	Exilim EX-Z850	•			
EX-S770	•				
<b>Concord</b>	1500	•			
	3047	•			
	4042	•			
	ES 500Z	•			
	Eye-Q 3040		•		
	Eye-Q 3341z		•		
	Eye-Q 3346Z	•			
	Eye-Q 4060z		•		
	Eye-Q 4360Z		•		
	Eye-Q 5062AF	•			
	Eye-Q 5345Z	•			
	Eye-Q 642	•			
	Eye-Q Duo 2000		•		
	<b>Contax</b>	i4R	•		
SL300RT		•			
TVS			•		
U4R				•	
<b>Creative</b>	DC-Cam 3000/3200z	•			
<b>DXG</b>	202V			•	
	305V			•	
	308		•		
	321		•		
	409	•			
	503		•		
	528		•		
	568			•	
<b>Epson</b>	L500V	•			
	Photo PC L-410	•			
<b>Fuji</b>	FinePix A330/340	•			
	FinePix A345/A350	•			
	FinePix A400/A500/A510	•			
	FinePix A600 Zoom	•			
	FinePix A700		•		
	FinePix E900			•	
	FinePix F11 Zoom	•			
	FinePix F20 Zoom	•			
	FinePix F30	•			
	FinePix F31fd	•			
	FinePix F460	•			
	FinePix F470	•			
	FinePix F650 Zoom		•		
	FinePix F710/F810	•			
	FinePix M603		•		
	FinePix V10	•			
	FinePix Z1 Zoom	•			
	FinePix Z2	•			
	FinePix Z3	•			
	Q1 Digital			•	

LOWEPRO RIDGE SERIES MATRIX 2006

		 Ridge 10	 Ridge 20	 Ridge 30	 Ridge 60
HP	Photosmart E317	•			
	Photosmart E327	•			
	Photosmart M22/M23		•		
	Photosmart M415		•		
	Photosmart M417/M517		•		
	Photosmart M425	•			
	Photosmart M525	•			
	Photosmart M527		•		
	Photosmart R507	•			
	Photosmart R607 SE	•			
	Photosmart R707/R717		•		
	Photosmart R727	•			
	Photosmart R817	•			
	Photosmart R818	•			
Photosmart R927	•				
Kodak	DX6490/7590/Z7590				•
	DX7630/7440			•	
	Easyshare C300			•	
	Easyshare C310		•		
	Easyshare C330		•		
	Easyshare C340		•		
	Easyshare C360		•		
	Easyshare C433		•		
	Easyshare C443		•		
	Easyshare C530	•			
	Easyshare C533		•		
	Easyshare C643		•		
	Easyshare C663		•		
	Easyshare C743		•		
	Easyshare C875				•
	Easyshare LS743/753	•			
	Easyshare One	•			
	Easyshare P712				•
	Easyshare P850				•
	Easyshare P880				•
	EasyShare Picture Viewer	•			
	EasyShare V530	•			
	EasyShare V550	•			
	Easyshare V570	•			
	Easyshare V603				•
	Easyshare V610		•		
	Easyshare Z612				•
	Easyshare Z650				•
	Easyshare Z700				•
	Easyshare Z705	•			
	Easyshare Z710				•
	Easyshare Z730			•	
Easyshare Z740				•	
Easyshare Z760			•		
EZ-200		•			
V550	•				
Kyocera	Finecam L3V/L4V/L30		•		
	Finecam S3/S3L/S3X/S4/S5/S5R	•			
	SL300R/400R	•			
Leica	C-Lux 1	•			
	D-Lux 2	•			
	D-Lux 3	•			
Minox	DC-6211	•			
Mustek	DV-3032			•	
	DV-4000		•		
	DV-4500			•	
	GSmart D35		•		
	MDC-5000	•			

LOWEPRO RIDGE SERIES MATRIX 2006

		 Ridge 10	 Ridge 20	 Ridge 30	 Ridge 60
<b>Nikon</b>	Coolpix 4600/5600		•		
	Coolpix 5900/7900		•		
	Coolpix 7600		•		
	Coolpix L2, L3, L4	•			
	Coolpix L6	•			
	Coolpix P1		•		
	Coolpix P2		•		
	Coolpix P3, P4		•		
	Coolpix S1	•			
	Coolpix S10			•	
	Coolpix S2	•			
	Coolpix S3	•			
	Coolpix S4			•	
	Coolpix S5	•			
	Coolpix S6	•			
	Coolpix S7c	•			
Coolpix S8	•				
Coolpix S9	•				
<b>Olympus</b>	µ digital 600	•			
	AZ-1/Ferrari Digital	•			
	AZ2	•			
	C-350/C-460z/460 Del Sol			•	
	C-360/C-450/C-460/D-395/D-575/D-580Z		•		
	C-40 Zoom/D-40 Zoom				•
	C-470/D-590		•		
	C-50/C-60			•	
	C-5060/C-7070 Wide Zoom				•
	C-5500/C-55 Sport Zoom				•
	C-7000/C-70			•	
	C-745/750/760/765 UZ				•
	D-390			•	
	D-425		•		
	D-435		•		
	D-535z/C-370z			•	
	D-540/560/565			•	
	D-545		•		
	D-595		•		
	D-630	•			
	FE-100			•	
	FE-110			•	
	FE-115			•	
	FE-120		•		
	FE-130	•			
	FE-140	•			
	FE-150	•			
	FE-170		•		
	FE-180	•			
	FE-190	•			
	FE-200	•			
	IR-300	•			
	IR-500	•			
	M:Robe 500	•			
	SP-310		•		
	SP-320		•		
SP-350		•			
SP-500UZ				•	
SP-510UZ				•	
SP-700	•				

LOWEPRO RIDGE SERIES MATRIX 2006



Ridge 10



Ridge 20



Ridge 30



Ridge 60

		Ridge 10	Ridge 20	Ridge 30	Ridge 60
Olympus	Stylus 1000/Mju Digital 1000	•			
	Stylus 300/400/410/Mju digital	•			
	Stylus 500/Mju Digital 500	•			
	Stylus 600	•			
	Stylus 700	•			
	Stylus 720SW	•			
	Stylus 725AW	•			
	Stylus 730/Mju Digital 730	•			
	Stylus 740/Mju Digital 740	•			
	Stylus 750/Mju Digital 750	•			
	Stylus 800/Mju Digital 800	•			
	Stylus 810	•			
	Stylus Verve/Verve S/μ-Mini/Mju Mini Digital	•			
	Panasonic	DMC LZ3/LZ5			•
DMC-F1S/F1K			•		
DMC-F7			•		
DMC-FX01			•		
DMC-FX1/FX1BS/FX5/FX5BS		•			
DMC-FX2/FX2B/FX7/FX7B		•			
DMC-FX50		•			
DMC-FX8		•			
DMC-FX9		•			
DMC-LC20				•	
DMC-LC33/43				•	
DMC-LC50/50B/70/70B/80/80B			•		
DMC-LZ1/LZ2			•		
Lumix DMC LS2		•			
Lumix DMC-LS1		•			
Lumix DMC-LX2					•
Lumix DMC-TZ1				•	
NV10		•			
SV-AS10		•			
SV-AV100			•		
SV-AV25	•				
SV-AV50	•				
Pentax	Optio 30		•		
	Optio 33L/33LF			•	
	Optio 33WR/43WR		•		
	Optio 450/550/555			•	
	Optio 50	•			
	Optio 50L	•			
	Optio 60	•			
	Optio 750Z			•	
	Optio A10	•			
	Optio A20	•			
	Optio E10		•		
	Optio E20		•		
	Optio L20	•			
	Optio M10	•			
	Optio M20	•			
	Optio MX/MX4				•
	Optio S/S4/S4i/S5i	•			
	Optio S30		•		
	Optio S40	•			
	Optio S45	•			
	Optio S55	•			
	Optio S5n	•			
	Optio S5z	•			
	Optio S6	•			
	Optio S60	•			
	Optio S7	•			
	Optio SV	•			
	Optio T10	•			
	Optio W10	•			
	Optio W20	•			
Optio WP	•				
Optio Wpi	•				

LOWEPRO RIDGE SERIES MATRIX X 2006



Ridge 10



Ridge 20



Ridge 30



Ridge 60

		Ridge 10	Ridge 20	Ridge 30	Ridge 60
<b>Polaroid</b>	PDC-3070			•	
	PhotoMAX 320			•	
	PhotoMAX Fun 640 SE			•	
	X530				•
<b>Praktica</b>	DC 44			•	
	DC Slim 5		•		
	DCZ 5.3			•	
	G 2.0	•			
<b>Ricoh</b>	Caplio 300G				•
	Caplio 400G Wide				•
	Caplio 500G Wide				•
	Caplio G3/G4			•	
	Caplio GX/GX-8	•			
	Caplio R1v	•			
	Caplio R2	•			
	Caplio R3	•			
	Caplio R30	•			
	Caplio R40	•			
	Caplio RR30		•		
	Caplio RR530	•			
	Caplio RX	•			
	GR Digital	•			
<b>Rollei</b>	da5324	•			
	dp8300	•			
	dr 5	•			
	Prego da6		•		
	Prego dp4200	•			
	Prego dp5300/6300		•		
	Prego dp6200	•			
	Prego dp6500	•			
	Prego dr5100	•			
<b>Samsung</b>	Digimax 200		•		
	Digimax 202		•		
	Digimax 240/420			•	
	Digimax 301		•		
	Digimax 3500/4500		•		
	Digimax 35MP3		•		
	Digimax 370/430		•		
	Digimax 530			•	
	Digimax 800k			•	
	Digimax A4/A5/A6		•		
	Digimax A40		•		
	Digimax A400		•		
	Digimax A402	•			
	Digimax A50	•			
	Digimax A502	•			
	Digimax A503	•			
	Digimax A55W	•			
	Digimax A7	•			
	Digimax i5	•			
	Digimax i6 PSP	•			
	Digimax L50	•			
	Digimax L55W	•			
	Digimax L60	•			
	Digimax L70	•			
	Digimax S1000	•			
	Digimax S500/S600/S800	•			
	Digimax S700	•			
	Digimax U-CA 3	•			
	Digimax U-CA 401	•			
	Digimax U-CA 501/505	•			
	Digimax U-CA5	•			
	Digimax V5/V6/V50/V70		•		
Digimax V600/V700	•				

LOWEPRO RIDGE SERIES MATRIX 2006

		 Ridge 10	 Ridge 20	 Ridge 30	 Ridge 60
<b>Samsung</b>	NV10	•			
	NV3	•			
	NV7 OPS		•		
	SCD363				•
	SC-M105	•			
	SC-X105L	•			
<b>Sanyo</b>	DSC-S5 Xacti	•			
	VPC DSC-J1			•	
	VPC-AZ3/VPC-MZ3	•			
	VPC-C5 Xacti	•			
	VPC-C6 Xacti	•			
	VPC-J4 Xacti	•			
	VPC-SX500			•	
	VPC-X360			•	
	VPC-Z400				•
	Xacti DSC-E6	•			
Xacti DSC-S6	•				
<b>Sony</b>	DSC-F88	•			
	DSC-L1	•			
	DSC-M1	•			
	DSC-M2			•	
	DSC-N1	•			
	DSC-N2	•			
	DSC-P100/P120		•		
	DSC-P150/P200		•		
	DSC-P41/P43		•		
	DSC-P73/93		•		
	DSC-S40	•			
	DSC-S500	•			
	DSC-S60			•	
	DSC-S600			•	
	DSC-S80			•	
	DSC-S90			•	
	DSC-T10	•			
	DSC-T30	•			
	DSC-T33	•			
	DSC-T5	•			
	DSC-T50	•			
	DSC-T7	•			
	DSC-T9	•			
	DSC-V3				•
	DSC-W100	•			
	DSC-W15		•		
	DSC-W17		•		
DSC-W30, W50, W70	•				
DSC-W5/W7		•			
<b>Toshiba</b>	PDR-3340		•		
	PDR-T30	•			
<b>UMAX</b>	Astrapix 610	•			
	Astrapix A680	•			

**LOWEPRO RIDGE SERIES MATRIX 2006**



**Ridge 10**



**Ridge 20**



**Ridge 30**



**Ridge 60**

Vivitar		Ridge 10	Ridge 20	Ridge 30	Ridge 60
DVR-210			•		
DVR-310			•		
DVR-410			•		
V3105	•				
V3315			•		
V3345/3355	•				
V3650	•				
V3695			•		
V3705/3715				•	
V3740	•				
V3750	•				
V3825				•	
V3826			•		
V5388	•				
V6300			•		
V7310	•				
Vivicam 10			•		
Vivicam 25	•				
Vivicam 3780	•				
Vivicam 4000			•		
Vivicam 4345	•				
Vivicam 5385	•				
Vivicam V2655			•		
Vivicam V3200				•	