



	Lens Case 1M	Lens Case 1S	Lens Case 1W	Lens Case 1N	Lens Case 1	Lens Case 2s	Lens Case 2	Lens Case 3	Lens Case 4S	Lens Case 4	Lens Case 5S	Lens Case 5	Lens Trekker 600 AW	
Konica-Minolta	16mm f2.8 fisheye		•											
	20mm f2.8		•											
	24mm f2.8		•											
	28mm f2		•											
	28mm f2.8		•											
	35mm f1.4 G		•											
	35mm f2		•											
	50mm f1.4		•											
	50mm f1.7		•											
	50mm f2.8 (D) Macro		•											
	50mm f3.5 Macro		•											
	85mm f1.4 G (D)		•											
	100mm f2.8 (D) Macro				•	•								
	100mm f2.8 Soft Focus		•											
	135mm f2.8 STF					•								
	200mm f2.8 APO G							•						
	200mm f4 APO G Macro								•					
	300mm f2.8 APO G (D) SSM												•	
	300mm f4 APO G										•			
	400mm f4.5 APO G												•	
	600mm f4 APO G													•
	500mm f8 REFLEX (mirror)													
	17-35mm f2.8-4 (D)					•					•			
	17-35mm f3.5 G					•								
	20-35mm f3.5-4.5			•										
	24-50mm f4	•												
	24-85mm f3.5-4.5			•										
	24-105mm f3.5-4.5 (D)	•												
	28-70mm f2.8 G					•								
	28-75mm f2.8 (D)				•									
	28-80mm f3.5-5.6													
	28-100mm f3.5-5.6 (D)													
	35-80mm f4-5.6 II													
	70-200 f2.8 APO G (D) SSM													
	70-210mm f4.5-5.6 II					•					•			
	75-300mm f4.5-5.6 (D)					•								
	100-300mm f4.5-5.6 APO (D)					•								
	100-400 f4.5-6.7 APO													
	Macro Zoom 3x-1x f1.7-2.8													
	Teleconverter 1.4x (D) APO	•												
	Teleconverter 2x (D) APO	•												
	10.5mm f2.8G DX Fisheye	•												
	14mm f2.8													
	16mm f2.8D	•												
	18mm f2.8													
20mm f2.8	•													
24mm f2.8D	•													
28mm f1.4D		•												
35mm f2D	•													
AF 60mm f2.8D Micro	•													
AF 85mm f1.4														
AF 85mm f1.8	•													
AF DC 105mm f2				•										
AF 105mm f2.8 Micro				•										
AF DC 135mm f2														
AF 180mm f2.8														
AF-S 200mm f2G ED-IF VR														
AF 200 f4 Micro														
AF-S 300mm f2.8 VR														
AF-S 300mm f2.8D ED-IF II														
AF-S 300mm f2.8														
AFI 300mm f2.8														
AF-S 300mm f4 ED-IF														
AF-S 600mm f4														
AF-S 500mm f4														
AF-S 400mm f2.8														
AF-S DX 12-24mm f4 G														
AF-S 17-35mm f2.8														
AF-S DX 17-55mm f2.8 G														
AF 18-35mm f3.5-4.5														
AF-S DX 18-70mm f3.5-4.5 G														
AF-S DX 18-135mm f3.5-5.6G ED-IF														
AF 24-50mm f3.3-4.5	•													
AF 24-85 f2.8-4														
AF-S 24-85mm f3.5-4.5	•													
AF 24-120mm f3.5-5.6														

*Availability may vary depending on country and location



	Lens Case 1M	Lens Case 1S	Lens Case 1W	Lens Case 1N	Lens Case 1	Lens Case 2s	Lens Case 2	Lens Case 3	Lens Case 4S	Lens Case 4	Lens Case 5S	Lens Case 5	Lens Trekker 600 AW
Olympus E-Series													
7-14mm F4 ED													
EZ 11-22mm f2.8-3.5													
14-45mm f3.5-5.6		•											
14-54mm f2.8-3.5													
18-180mm F3.5-6.3		•											
35-100mm F2 PRO ED													
40-150mm f3.5-4.5													
50-200mm f2.8-3.5 ED													
90-250mm F2.8 PRO ED													
8mm Fisheye f3.5 ED													
50mm f2 ED Macro	•												
150mm f2 ED													
300mm f2.8 ED													
EC14 1.4x Converter	•												
EX25 Extension Tube	•												
Pentax (MF)													
15mm f3.5													
16mm f2.8 fisheye		•											
20mm f2.8	•												
28mm f3.5 Shift													
50mm f1.2	•												
200mm f2.8 ED													
300mm f2.8 ED (IF)													
500mm f4.5													
400mm f2.8 ED (IF)													
400mm f5.6													
1000mm f11 mirror													
35-80mm f4-5.6	•												
Pentax AF													
F Series													
31mm f1.8 FA AL Limited	•												
43mm f1.9 FA Limited	•												
77mm f1.8 FA Limited	•												
50mm f2.8 FA Macro	•												
100mm f2.8 FA Macro													
100mm f3.5 FA Macro	•												
17-28mm f3.5-4.5													
35-80mm f4-5.6		•											
80-200mm f4.7-5.6													
100-300mm f4.5-5.6													
100-300mm f4.7-5.8 FA													
Pentax AF													
14mm f2.8 ED													
20mm f2.8	•												
24mm f2 AL (IF)	•												
28mm f2.8 AL													
35mm f2 AL	•												
50mm f1.4	•												
50mm f1.7	•												
85mm f1.4 (IF)													
85mm f2.8 Soft Focus													
135mm f2.8 (IF)													
200mm f2.8 ED (IF)													
300mm f2.8 ED (IF)													
300mm f4.5 ED (IF)													
600mm f4 ED (IF)													
10-17mm f3.5-4.5 ED													
12-24mm F4 ED AL													
16-45mm f4 ED AL													
18-55mm F3.5-5.6 AL	•												
20-35mm f4 AL	•												
24-90 f3.5-4.5 AL	•												
28-200mm f3.8-5.6 AL (IF)													
28-70mm f2.8													
28-70mm f2.8 AL Power Zoom													
28-70mm f4 AL													
28-80mm f3.5-5.6													
28-90 f3.5-5.6	•												
28-105mm f4-5.6 Power Zoom													
70-200mm f4-5.6 Power Zoom													
75-300 f4.5-5.8 AL													
80-200mm f2.8 ED (IF)													
80-320mm f4.5-5.6													
250-600mm f5.6 ED (IF) Power Zoom													
1.7x Converter	•												
Sony													
SAL 50mm f/1.4	•												
SAL 18-200mm f/3.5-6.3 Aspherical ED													
SAL 75-300mm D f/4.5-5.6													

*Availability may vary depending on country and location

		 Lens Case 1M	 Lens Case 1S	 Lens Case 1W	 Lens Case 1N	 Lens Case 1	 Lens Case 2s	 Lens Case 2	 Lens Case 3	 Lens Case 4S	 Lens Case 4	 Lens Case 5S	 Lens Case 5	 Lens Trekker 600 AW	
Sigma	8mm f3.5 EX DG Fisheye	•													
	8mm f4 EX Circular Fisheye	•													
	14mm f2.8 EX Aspherical / HSM					•									
	15mm f2.8 EX Diagonal Fisheye	•													
	20mm f1.8 DG Aspherical (RF)			•											
	24mm f1.8 EX DG Aspherical Macro					•									
	28mm f1.8 EX DG Aspherical Macro					•									
	30mm f1.4 EX DC-HSM AF	•													
	50mm f2.8 EX DG Macro	•													
	105mm f2.8 EX Macro				•										
	150mm f2.8 EX DG Macro / HSM														
	180mm f3.5 APO EX (IF) / HSM									•					
	300mm f2.8 EX DG HSM												•		
	500mm f4.5 EX DG														•
	600mm f8 Mirror										•				
	10-20mm f4-5.6 EX DC HSM						•								
	12-24mm f4.5-5.6 EX DSG Aspherical / HSM						•								
	15-30mm f3.5-4.5 EX DG Aspherical						•		•						
	17-35mm f2.8-4 EX Aspherical / HSM						•								
	18-50mm f2.8 EX DC				•										
	18-50mm f3.5-5.6 DC	•													
	18-125mm f3.5-5.6 DC			•											
	18-200mm f3.5-6.3 DC			•											
	20-40mm f2.8 EX DG Aspherical				•										
	24-60mm f2.8 EX DG Aspherical				•										
	24-70mm f2.8 EX DG Macro				•										
	24-70mm f2.8 EX DG Aspherical DF				•										
	24-70mm f3.5-5.6 HF			•											
	24-135mm f2.8-4.5 Aspherical (IF)						•								
	28-70mm f2.8 EX DG				•										
	28-70mm f2.8-4 Compact Zoom	•													
	28-80mm f3.5-5.6 II Aspherical			•											
	28-105mm f2.8-4 Aspherical			•											
	28-105mm f3.8-5.6 UC III Aspherical (IF)			•											
	28-135mm f3.8-5.6 Aspherical (IF) Macro			•											
	28-200mm f3.5-5.6 Aspherical Compact Macro			•											
	28-300mm f3.5-6.3 Aspherical Macro Hyperzoom				•										
	50-150mm f2.8 EX DC HSM							•							
	50-500mm f4-6.3 APO EX (RF) HSM													•	
	55-200mm f4-5.6 DC				•										
	70-200mm f2.8 APO EX HSM									•					
	70-300mm f4-5.6 DL Macro Super II						•								
	70-300mm f4-5.6 APO Macro Super II						•								
	80-400mm f4.5-5.6 APO EX OS						•							•	
	100-300mm f4.5-6.7 DL						•								
100-300mm f4 APO EX (IF)											•				
120-300mm f2.8 APO EX (IF) HSM											•			•	
135-400mm f4.5-5.6 Aspherical (RF)									•					•	
170-500mm f5-6.3												•		•	
300-800mm f5.6 APO EX (IF) HSM														•	
SP 14mm f2.8 Aspherical (IF)						•									
SP 90mm f2.8 Di Macro					•										
SP 180mm f3.5 Di LD (IF) Macro								•							
SP 300mm f2.8 Aspherical (IF)														•	
SP 11-18mm f4.5-5.6 DII LD														•	
SP 17-35mm f2.8-4 Di LD Aspherical (IF)														•	
AF 17-50mm f2.8 XR Di II				•											
AF 18-200mm f3.5-6.3 XR DII LD															
AF 19-35mm f3.5-4.5														•	
SP-AF 20-40mm f2.7-3.5 IF														•	
SP 24-70mm f3.5-5.6 LD F	•														
SP 28-75mm f2.8-4 Di														•	
SP 70-210mm 2.8 AF														•	
AF 75-300 f4-5.6 LD Macro														•	
200-400mm 5.6 LD F														•	
SP 200-500mm f5-6.3 Di LD														•	
XR 28-300mm f3.5-6.3 Di LD Aspherical (IF) Macro														•	
SP 24-135mm f3.5-5.6 AD Aspherical (IF)														•	
28-80mm f3.5-5.6 Aspherical	•														
28-105mm f4-5.6 (IF)	•														
SP 28-105mm f2.8 Aspherical (IF)														•	
28-200mm f3.8-5.6 Aspherical (IF) Macro														•	
70-300 f4-5.6 LD Macro														•	
80-210mm f4-5.6														•	
100-300mm f5.6 F														•	

*Availability may vary depending on country and location

	 Lens Case 1M	 Lens Case 1S	 Lens Case 1W	 Lens Case 1N	 Lens Case 1	 Lens Case 2s	 Lens Case 2	 Lens Case 3	 Lens Case 4S	 Lens Case 4	 Lens Case 5S	 Lens Case 5	 Lens Trekker 600 AW	
Tokina	AT-X 12-24mm f4 AF Pro													
	AT-X 19-35mm f3.5-4.5 (IF)													
	AT-X 24-200 f3.5-5.6 (IF)													
	AT-X 80-400mm f4.5-5.6 (IF) II													
	AT-X PRO 20-35mm f2.8													
	AT-X PRO 28-70mm f2.8 SV													
	AT-X PRO 28-80mm f2.8													
	AT-X PRO 80-200mm f2.8													
	AT-X 100-300mm f4 AF II													
	AT-X PRO 300mm f2.8													
SZ-X 28-200mm f3.5-5.3														